

Accurate CO₂ measurement for working safety in breweries and wineries



Carbon dioxide safety measurement is especially needed in breweries.

Carbon dioxide is used for the carbonation of beverages. CO₂ is the gas that gives the fizz to soft drinks and sparkling wines. In breweries, CO₂ is recovered as a by-product of fermentation. As high concentrations of CO₂ are clearly hazardous, most countries, including the USA, have set workplace exposure limits. Carbon dioxide monitoring is essential for employee safety in the brewing and carbonated drinks industry.

Carbon dioxide can be a safety hazard. When CO₂ rises, people start feeling tired. Very high concentrations can lead to unconsciousness or even death. Occupations where carbon dioxide can rise to dangerous levels include the brewing and carbonated drinks industries, as well as wineries. It is therefore vital to measure the level of carbon dioxide in every place where there is a risk of CO₂ build-up or leakage.

Most countries have set workplace exposure limits for CO₂. For instance, in the United States,

OSHA's (Occupational Safety & Health Administration, U.S. Department of Labor) general exposure limit of CO₂ to not exceed 5,000 ppm during an eight hour working shift.

Carbon dioxide safety measurement is especially needed in beverage production, because the fermentation tanks have pressure relief valves. If the pressure in the tanks builds up too high, the gas will exit through these valves. There is also a risk that gas can leak from the tanks or pipelines.

Measuring CO₂ in breweries

Carbon dioxide is generated as a natural process of fermentation and is found in most brewing tanks and around filler machines, packaging and closer areas. Excessive levels of carbon dioxide can displace oxygen, causing asphyxiation.

Breweries throughout the world therefore pose unique challenges to employee safety. There are various areas within a brewery where fermentation gases may collect, becoming a hazard to employees.

In some breweries, CO₂ is recovered as a by-product of fermentation. It can then be purified and compressed for further use. In beverage production the gas for carbonation is usually delivered by gas suppliers, because it has to be very clean in order not to affect the taste.

Confined spaces are among the most hazardous places in breweries. They include beer storage tanks, brew kettles, vats, sumps, pits and other confined areas where carbon dioxide may be present.

Safe CO₂ levels in wineries

Similar problems arise at wineries. During the fermentation process, wine grape sugar is metabolized by yeast which converts the sugar to water, alcohol and carbon dioxide. During the active fermentation process, concentrations of carbon dioxide within the headspace of a fermenting tank may reach levels approaching 100 % by volume.

From the trucking in and crushing of freshly harvested grapes to the final aging and bottling process, care must be taken to protect people from potential hazards. Areas of concern within wineries include pits, sumps and storage tanks, as well as fermentation rooms, barrel cellars and bottling rooms. Carbon dioxide is one of the main gas hazards.

The dangers posed by this type of CO₂ build-up include the displacement of oxygen and the potential asphyxiation of employees, as well as the dangers of being exposed to high concentrations of carbon dioxide for extended periods of time.

In wineries, too, the average exposure limit of CO₂ should be kept below 5,000 ppm during an eight hour working shift. In addition, during the active fermentation process, closed



buildings should be monitored for carbon dioxide build-up before entering, as concentrations may exceed safe levels.

Accurate and reliable CO₂ detection

The Vaisala CARBOCAP® Carbon Dioxide Probes [GMP251](#) and [GMP252](#) are intelligent, stand-alone probes with operating temperature range of -40 ... +60 °C. The GMP251 has a measurement range of 0 ... 20 % CO₂ while the GMP252

is intended for ppm ranges and has a measurement range of 0 ... 10 000 ppm CO₂.

The probes are easy to mount, while the sensors are accurate and durable. They have excellent long-term stability which will reduce maintenance costs over the years.

The Vaisala sensors enable reliable carbon dioxide detection to comply with the recommended expose limits and ensure the wellbeing of people working in wineries and breweries.

VAISALA

Please contact us at
www.vaisala.com/contactus



Scan the code for
more information

Ref. B211529EN-B ©Vaisala 2022

This material is subject to copyright protection, with all copyrights retained by Vaisala and its individual partners. All rights reserved. Any logos and/or product names are trademarks of Vaisala or its individual partners. The reproduction, transfer, distribution or storage of information contained in this brochure in any form without the prior written consent of Vaisala is strictly prohibited. All specifications — technical included — are subject to change without notice.

www.vaisala.com